

INSTALLATION INSTRUCTIONS

⚠ WARNING: DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER

56326 APPLICATIONS

Make	Model
Cadillac	XT5
GMC	Acadia (excluding Limited)

WIRING LOCATION GUIDE

SUVs, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

S6 - Behind center of rear bumper

CUSTOM WIRING CONNECTOR



NOTICE

All steps must be followed to ensure the CURT wiring connector will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

All connections must be complete for the wiring harness to function. Test and verify installation of product with test light or trailer after installment. For initial test, reset electrical system of the vehicle by temporarily removing the vehicle's key from the ignition.

TOOLS NEEDED

Wire cutter

⚠ WARNING

Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Stop / Turn Light - 10 amps

Taillights - 10 amps

Backup - 10 amps

Power Circuit - 30 amps

Trailer Brakes: 3 Axles / 6 Brakes - 20 amps

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

Step 2

Locate the vehicle connector behind the rear bumper in the center of the vehicle. The connector will be similar to that on the CURT wiring connector (A).

Step 3

Separate the vehicle connectors from the weather seal connectors. Take care not to damage the locking tabs.

Step 4

Insert the CURT wiring connector end into the vehicle connector. Make sure the connectors are fully inserted with locking tabs in place.

Step 5

Determine the 7-way mounting location. Route the other end of the wiring connector along the inside of the bumper towards the center of the vehicle and to the 7-way mounting location.

Step 6

Insert the 7-way connector end in between the separated 7-way connectors. Make sure the connectors are fully inserted with locking tabs in place.

Step 7

Reinstall all items removed during install and reconnect negative battery terminal.

